



WEATHERSAFE
YOUR NATURAL FLOOR STYLE INSIDE AND OUT

NATURE

**SOLUTION
DYED**



CHEVRON BEIGE 34



CHEVRON BROWN 32



CHEVRON GREY 37



CHEVRON GRAIN 26



RHYTHM GREY 38



RHYTHM GRAIN 27



WICKER GREY 37



WICKER GRAIN 26

For accurate colour references, please refer to a sample swatch.

Yarn	Enhanced UV Protected & Weathersafe Solution Dyed Polypropylene
Backing	Latex Back
Total Weight	+/- 1640gsm
Total Thickness	+/- 5mm
Location Grade	Medium Commercial
Width	4m
Guarantees	5 year maintenance linked
Warranties	10 year limited wear

Bill of Quantities

Nature (+ colour name) Latex Back
Medium Commercial broadloom tufted
carpets by Floornet, available in 4m wide and
made from Enhanced UV Protected &
Weathersafe Solution Dyed Polypropylene,
with a total thickness of +/- 5mm and a total
weight of +/-1640gsm, to be laid in
accordance with the code of practice for the
installation of textile floor coverings
(SANS 10186).

Important Information

- Care must be taken when ordering or installing carpets. Like all textile products, it is subject to shade variation between batches.
- Due to dye lot variations, actual material may vary from samples. Certain light sources shining across the surface may emphasise the effect of shadow lines. These are not a manufacturing defect and will not detract from the performance of the carpet.
- Adequate precautions must be taken to protect the carpet against sunlight to prevent premature fading or damage.
- Regular vacuum cleaning is essential. Spills and surface stains can be removed by sponging with a damp cloth, or for more resistant stains, with a mild detergent solution. Use carpet protector mats for chairs with castor wheels.
- A well maintained carpet can reduce airborne allergens, contributing to healthier indoor air quality. Unlike other surfaces, carpet traps dust particles, which keeps them out of the air, and allows them to be easily vacuumed up.



FLOORNET

**SOLUTION
DYED**



WEATHERSAFE
YOUR NATURAL FLOOR SERVICE ANYWHERE ANYTIME

There are several key methods and techniques to ensure a successful installation when fitting our flat-weave Nature carpet. Here's an explanation of fitting methods and some important considerations regarding joining and pattern-matching.

Nature can be fitted in two different ways:

1. Full stick down (indoors and outdoors)

- This method involves sticking the carpet directly to the floor using a suitable adhesive. It's a secure installation technique, minimising movement.

2. On grippers and underlay (indoors only)

- This traditional method uses tension to hold the carpet in place over an underlay.
- It is advisable to use a double row of carpet grippers (short pin grippers are recommended) to secure the edges, as a single row may not provide sufficient hold.
- Stretching must be executed gently (without overstretching) to avoid damage or misalignment.

Joining and Pattern-matching

The woven edges are prone to fraying. To prevent this, seal the edges using contact glue for darker, earthy colours and latex for lighter shades. Any visible edges should be sealed.

- Always be very careful not to get the glue on the surface pile.
- The same procedure needs to be applied to the edges against the wall, where the carpet cannot be neatly tucked in under the skirting or covered with a quarter round or strip.
- Take care not to cut the carpet too short where needed to be tucked in under skirting or door strips.
- It is advisable to use a wider and stronger joining tape as this will give you more stability on either side of the joins.
- Regularly replace cutting blades to maintain precision and cleanliness in your cuts, a blunt blade will drag and tear, causing frayed edges.
- The cutting should be done from the top with a sharp knife. For a perfect join the knife should be held slightly tilted.
- Do not do cross joins as they can create visible seams and disrupt the pattern, instead do seam joins only.
- When doing a seam join, both pieces of carpet should be cut separately. Never lay them on top of each other and cut through both of them at the same time.
- It is recommended to cut through the low pile instead of the high pile where possible.

Installing flat weave carpets such as Nature, invariably requires more time and meticulous attention compared to other types. This is due to their unique properties and the careful steps needed to ensure a successful installation. Attention to detail at each stage is crucial to achieving a high-quality, durable finish.